

Assembly Instruction

Portable Mount with Suction Cup for Starlink Mini

Step 1: Prepare the Kickstand



In this step, you are looking at the back differ disclared included with your Stantisk Min package. Notice the two grooves running along the back. Each groove contains two holes specifically designed for square-headed scews. When positioning the screws, make sure that the square head of each screw along specificity with the grooves. The edges of the screw head should if flush against the sides of the groove, ensuring that the screw can be smoothly inserted into the holes without obstruction.

Step 2: Attach the Kickstand to the Main Plate




In this step, you will attach the kickstand to the main plate. Begin by aligning the square-headed screws with the corresponding holes in the middle of the main plate, as shown in the image. Carefully inset the threaded end of the screws into the holes, ensuring that the kickstand is securely positioned against the main plate.

Step 3: Secure the Kickstand with Hexagonal Nuts



In this step, we flip the assembly around to show the opposite side of the main plate. Once flipped, you will see the two screws from the previous step prorfuling through the plate. Now, take the two small hexagonal platis-headed nuts and screw them onto the exposed threads. Tighten the nuts by hand to ensure the kickstand is ascrew/ fastened to the main plate.

Step 4: Attach the Suction Cups



In this step, place the four suction cups underneath the plate assembly. Ensure that each suction cup is aligned with the corners of the assembly. Insert the screws on the suction cups through the holes at each corner of the assembly, allowing them to protrude through the plate. This will secure the suction cups in place and ensure the assembly is ready for mounting.

Step 5: Secure the Suction Cups



In this step, secure the four suction cups to the main plate by lightening a hexagonal plassic-headed nut for each suction cup. Make sure to lighten each nut firmly to ensure the suction cups are securely fastened to the plate for a stable and reliable hold.

Step 6: Attach the Assembly to Your Starlink Mini



In this step, take the completed assembly and attach it to the back of your Starlink Mini antenna. Insert the kickstand into the designated slot on the back of the anterna. Push firmly until you hear a "click," indicating that the kickstand is securely fastened, and the installation is complete.

Step 7: Secure the Exposed End with the End-Cap Securing Plate



In this final step, you will protect the previously exposed end of the Starlink Mini by attaching the End-Cap Securing Plate. Position the plate over the exposed area and secure it using the round-headed, anti-slip screw. Tighten the screw to ensure the plate is firmly in place, providing added protection and stability to the assembly.



Once the assembly is mounted onto a surface--whether its plaskic wood plass, or steel--gow will need to activate the suction cups to ensure a strong and secure attachment. To do this, use the Suction Pump Pumper (the finger-like methasism attached to each suction cup). Pump the plunger repeatedy until the red line on the plunger is no longer visible. This indicates that the suction force is at full capacity and the assembly is securely atched to the surface.

Important Note:

Please regularly check the Suction Pump Plungers. If the red ine becomes visible again, it indicates that the suction force has weakened. Simply pump the plunger until the red line disappears to ensure the mount remains securely attached.